


Microwave



The Deepdish Crisper

Instructions	3
The Deepdish Crisper	4
Crisping Dish	
Cooking Charts	5
Bacon & Avocado Sandwich	6
Chicken Pita Pockets	7
Pork Ribs with Quick BBQ	Sauc∈
Salmon Burgers with CrŁme	Fr9ai
Beef Burgers with Spicy S	1a01 sa
Flapjacks, Potato Bake	11
Thai Cod Bites	12
Chocolate Tart	13
Mini Sponges/G@noise	14



Instructions

Preheat Instructions

- 1. Place the pan in the centre of the glass turntable.
- 2. Preheat the empty dish for the times listed below.
- 3. Place food to be cooked on the pan, cover with lid and cook mended time.
- 4. Second and subsequent batches do not need additional prehe

Preheat times:

Oven 750W 850W 1000W 1200W 1500W Time 75 sec 60 sec 50 sec 40 sec 30 sec

For increased crispyness add 30 seconds to the prehe WARNING - do not preheat for more that twice the record time

Cooking Times

Always use the lid with the crisper

The recipes shown in this cookbook are tested in an 1100W You should increase or decrease the cooking times as below

For 750 watt ovens: add 20 seconds per minute For 850 watt ovens: add 15 seconds per minute For 1200 watt ovens: subtract 5 seconds per minute

For 1500 watt ovens: subtract 15 seconds per minute Times given are estimates only. You should always check that focoked fully.

Safety Instructions

Always protect your hands when handling the dish.

Preheating times are from cold.

Although this is a metal dish, it is safe to use in the microwave absorbent layer on the underside.

Dish washer safe.

Do not preheat for more than twice the recommended time.

For microwaves without turntables, rotate the Crisping Dish 1 through preheating.

Always use plastic or non-stick safe utensils.

Read hints and tips section, all things you need to know abou techniques are here.

Failure to follow the above will result in damage to your cri

The Deepdish Crisper

Congratulations on your purchase of a great new inrevation from Waveware. Our new Crisper lid not only extends the life of your oven by protecting it from splashes and deposits of food residue but it also demicrowave energy to the under

of the dish. This extra ergenerates a hot crisping to better sear the food us the nice crispy crust know and love.

More Uniform Cooking

Microwave ovens have a tendency to overcook the side and undercook the center. The raised metal edges of crisper balance this by shielding the sides and divergence microwave energy to the center. This ensures perfectly balanced cooking

Better Crisping

The Deepdish Crisper diverts more of the microwave energy to the underside of the crisper. This enhance the crisping function and allows for much shorter placed times. There is now no need to reheat the cribetween cooking batches—simply load the next batch and start cooking.

Cooking Times


All times are to be used after preheating

Food		Quantity	Cooking Time
Thin crust pizza		1	4/5 minutes
Thick crust pizza		1	7/8 minutes
Hash Browns	* Fresh	2	5 minutes
Chicken Nuggets	* Frozen	6-10	5 minutes
Streaky Bacon	* Fresh	5	6 minutes
Chicken Tenders	* Frozen	2	5 minutes
Chicken Tenders	* Fresh	2	4 minutes
Beef Burgers	* Frozen	2	5 minutes
Beef Burgers	* Fresh	2	4 minutes
Fish Cakes	* Frozen	2	5 minutes
Fish Cakes	* Fresh	2	4 minutes
Fish Sticks	* Frozen	4	5 minutes
Breaded Fish Fillet	* Frozen	1	5 minutes
Fresh fish fillet	* Fresh	1	4 minutes
Breaded chicken fille	t * Fresh	1	5 minutes
Fresh chicken fillet	* Frozen	1	4 minutes
Gammon Steak	* Fresh	1	4 minutes
Steak (Medium)	*Fresh	1	4 minutes
Bagel Bites	Frozen	4	1 minutes
French fries	* Frozen	1 dish	6 minutes
Onion Rings	* Frozen	1 dish	5 minutes

Foods marked with * should be turned half way through cooki

Pizzas with uncooked bases are not suitable for the mid wish to make your own pizza, we would suggest that you pre-baked base in the supermarket.

Bacon & Avocado Ciabatta



To Assemble:

Preheat the Crisper as directed on page 3.

Place 5 strips of bacon across the pan and cook for 3 minutes side and 2 minutes on the second side.

Repeat for the second batch of bacon.

Cut the bread in half and brush with olive oil.

Place the bacon on the bread. Top with the sliced tomatoes, cados.

Season lightly, replace the top of the bread and enjoy!

Chicken Pita Pockets



Another high speed recipe idea for a busy lifestyle ready in 10 minutes. For variety, try strips of lean pork i place of chicken

Ingredients

1 lb / 450g Lean chicken 2 Peppers, deseeded and cut into squares 4 Wooden skewers 1 tablesp.Curry paste 1 tablesp.Oil Salt and black pepper

To Serve:

Mixed salad leaves Olive oil and lemon juice 4 pita breads, toasted Greek-style yogurt or mayonnaise (optional Pinch salt



To Cook:

Cut the chicken into even chunks inadbouthick)

Mix the curry paste, oil and seasoning. Pour it over the chic well.

Thread the chicken and peppers onto the skewers.

Preheat the Crisper as directed on page 3.

Cook for 3minutes on a high setting, turn, then cook for a fu minutes.

To check if the chicken is cooked thoroughly, cut into the la near the centre if the dish. If it is pink, then cook for an minute.

When cooked, leave to stand uncovered for 1 minute.

Pork Ribs With Quick Barbecue Sauce

These ribs are par-boiled before cooking, this will reduce the fat and ensure that they are fully cooked. The microwave allows the food absorb the flavor without having to marinade for hours.

Serves 4
1kg (2lbs) Pork ribs

Boil the ribs in a large pan of boiling water for 10 minutes.

You can flavor the liquid with onion and tsp. of spice powder, but this is not essential. Drain and leave in the fridge until ready.

Quick Barbecue Sauce:

3 tablesp. Tomato ketchup

1 tablesp. Honey

1 tablesp. White wine vinegar

1 tablesp. Worcestershire sauce

dash Tabasco

1 Finely chopped red chilli (optional)

Salt and Pepper

To Cook:

Mix all the sauce ingredients together.

Brush all of the ribs thoroughly with the sauce.

Preheat the Crisper as directed on page 3.

Cook for 1/3 minutes on the first side on high

Brush on some extra sauce when turning them and then-cook for ther 3 minutes on high.

Rest for 1 minute before serving

Salmon Burgers

These are a wonderful variation on the traditional by Perfect for the kids coming in from school.

Ingredients:

1 lb 450g Salmon flesh – minced 1 cup 4 oz breadcrumbs 1 spring onion - finely chopped 1 clove garlic - finely chopped Grated zest and juice of 1/2lemon Salt and pepper 4 burger buns Shredded lettuce Sliced tomato 4 tablespoons crème fraiche with lemon zest added



To Cook:

Chopped chives

Add breadcrumbs, spring onion, lemon zest and garlic to salmos Season and moisten with lemon juice.

Form into patties. Chill for at least 1 hour. Preheatrisper as directed on apachecook for minutes on each side

Place on toasted buns with lettuce and tomato.

spoonful of crłme fraiche and sprinkle with chopped cnives.

Serve with salad or baked potato.

*You can substitute trout.

Beef Burgers with Spicy Red Pepp Salsa

The salsa complements these burgers wonderfully and is so easy to make.

The standing time is essen tial as it allows the burgers to cook thoroughly.

Burgers:

1 lb 450g Minced beef

1 Onion, finely chopped and cooked

2 tablesp. Chopped parsley

1 Egg yolk

Dash of soy sauce Salt and black pepper

To Prepare:

Mix the beef, onion, parsley 2 Tablesp. parsley or basil soy sauce, egg yolk and

seasoning together.

Shape into 4 burgers. Refrigerateake the salsa:

until

you are ready to cook.

Pre heat the Crisper as directed of make it as chunky or as

page 3.

ers at a time for 3 minutes on the

first side and 2 on the second side.

Ensure the burgers are cooked

Salsa:

1 Red pepper, de-seeded and chopped

2 Large tomatoes

1 Small onion, chopped

Juice of half a lemon

1 Green chilli, chopped

1-2 Tablesp. olive oil

Salt and black pepper

Add all of the ingredients to a

food processor and mix on pulse,

smooth as you like. Covering the crisper, cook two entry erate until ready to use.

This salsa is also great with steaks

Flapjacks

This recipe is a great way to get the kids into baki is very little waiting around before they re cooked!

Ingredients:

1 level tablesp Golden syrup

1/2 cup 4 oz Light brown sugar

1 stick 4 oz Butter

2 cups 6 oz Rolled oats

Small pinch of salt

Handful Raisins or Hazelnuts (optional)

Place the syrup, butter and sugar in a microwave proof bowl a on a medium setting for 1 minute or until melted, stir ha through.

Add the rolled oats, raisins and nuts (if using) and a pinch mix well

Put the mixture into the Crisping Dish and press down firmly level.

Cook for 5 minutes on high.

Cut into portions while still warm and leave in the tin until



Thai Fish Bites

Next time you have some left over potato, try making these fish They are low in fat, contain lots of good fish oil and pack a flavor. They are good for lunch or supper with some salad. Or y cut the cakes into quarters and serve on a platter for casual r on the TV with friends. Serves 4-6

Ingredients:

4 oz 110g Cooked Potatoes
 1 lb / 450g Cod Fillet, skinned and roughly chopped
 11/2 tblsp Thai Red Curry Paste

1 Egg

1 rind Lime, very finely sliced

1 tblsp Coriander, chopped

4 Chives, chopped

1 tblsp Plain Flour

For the Sweet Chilli Dip:

4 tblsp Soy Sauce
Juice of 1 Lime
1 Red Chilli, de-seeded and sliced thinly
Pinch of Sugar

Method

Place the cod, cooked potato, curry paste, egg and lime rind in a food processor and blend until smooth (or you could use a fork and mash to a rougher paste). Stir in the coriander and scallions.

To make the cakes take a small handful of fish mixture and shape it into a ball, flatten it slightly at the top and bottom. Continue making them until you have about 10-12 cakes.

Refrigerate for about 20 minutes before cooking.

To make the dipping sauce, place all the ingredients in a bowl and leave to infuse. Add a little more sugar to sweeten if you like (Alternatively you could just buy a sweet chilli sauce)

To cook the fish cakes, preheat the crisping dish as directed on page 3.

Place 4 cakes on the dish at a time Cook for 1/2 minutes

Turn and cook for a further 2 minutes

Chocolate Tart

This sinful tart is delicious when served slightly we 40 minutes

after cooking. The pastry is quick and easy to make

done in the food processor.

Sweet crust pastry:

11/₂ cup 9 oz Flour 11/₂ stick / 5oz Margarine/Butter 1 large Tbsp Icing Sugar 1 Egg yolk

Chocolate filling:

1 1/3 cup 350 ml Fresh cream 11 oz Plain Chocolate (about 55% cocoa solids, any more would be too bitter) 1 egg + 1 egg yolk

Pastry:

Beat the flour, butter and sugar in a food processor until crare formed.

Add the egg yolk and beat until the ingredients form dough.

Wrap the dough in Saran wrap and chill for 30 minutes.

Roll out the dough evenly and place on the preheased Crisping making sure it covers the whole surface, including the sides.

Cook for 5 minutes on high in the microwave.

Filling:

Warm the cream to just below boiling point.

Add the broken chocolate pieces and stir until melted.

Lightly whisk the egg and additional egg yolk in a cup and porchocolate mixture. Stir in thoroughly.

Pour the filling into the pastry case and microwave for 7 min um setting.

After this cook the tart for an additional 1-minute on high. The tart should have a wobble when you remove it from the mic Leave to cool for about forty minutes or until it has almost

Serve with whipped cream or valve la ice-cream.

Mini Sponges/GØnoise

These sponges fluff up beautifully in the microwave an geous served immediately with thick cream and berries.

Makes 16 sponges approx.

Ingredients:

Sponge 2 Medium Eggs 1/3 cup / 2 oz Castor Sugar 1/3 cup / 2 oz Self raising flour 1/2 tsp Vanilla Extract

Topping:

1/2 lb Strawberries 1 tablesp Castor Sugar 1 cup / 1/2 Pint Unsweetened Cream, whipped

To Cook:

Add eggs, vanilla essence and sugar to a mixing bowl.

Whisk until it makes a thick mousse.

Strain in the flour and fold gently with a metal spoon until it absorbed by the mixture.

Preheat the Crisping Dish as directed on page 3.

When fully heated quickly drop four dessert spoons of the mixtur Crisping Dish.

Cook for 45 seconds.

Turn and cook for a further 15 seconds.

If you wish to make more, preheat the Crisping Dish for an additional 45 seconds each time before using.

The sponges can be cooled on a wire rack, but are best eaten warm.

For the topping:

Wash the strawberries and

cut into chunks.

Place into a

microwave

proof bowl and heat

until sugar

has dissolved.

Stir it up to coa the strawberries.

The topping can be eaten either on

Tips

Did you know that you could DISSOLVE JELLY WITHOUT ADDING WATER? Just microwave for forty-five seconds. Then you can add water gradually, stirring continuously thereby reducing the set

If you have a jar of HONEY THAT HAS CRYSTALLISED remove the lid, place the jar in your microwave medium for two minutes.

To CLEAN your oven and REMOVE COOKING ODOURS, s-ii ply heat

a cup of water with a slice of lemon for 2-3min.

INCREASE THE JUICE FROM CITRUS FRUITS by heating for forty sec onds before squeezing.

DO NOT HEAT EMPTY PLATES in the microwave oven, as this can cause damage.

Did you know that SAUCES, SOUPS, CUSTARDS, etc. are FAST and EASY in a microwave? You don t have to keep stirring to get a s texture.

TO PEEL TOMATOES place 2 cups of boiling water in a container, add the tomatoes and heat on high for 1 min. Plunge water and the skin will peel off easily.

For TEAR-FREE ONIONS, trim the ends off and heat on high for 30 onds.

FRESHEN STALE CRACKERS, ROLLS OR BISCUITS by placing on a rack or double thickness of kitc heating for 1 min then allowing standing time

For BBQ PARTIES, most chefs agree that it is cook food (particularly meats) in the microwa on the barbecue.

and ١.

:e-

sh

Use evenly sized pieces of food for even cooking.

Reduce quantities of salt and pepper.



Microwave COOKBOOK

The Crisping Dish

ne One of the reasons people often disappointed with mic cooking is unappetising sog bases and crusts. This can be a p particularith foods such as pizza tries.

The Microbake Crisping Dish provi perfect solution to this problem. The hot Crisping tray sears and c to give conventional oven results microwave. Capable of cooking eve from frozen convenience foods oven chips and breaded fish) to h made pastries, pies and tarts, Th Microbake Crisping Dish is excell late night snacks or quick family



__his unique innovation diverta al energy to the underside o: crisper. This enhances the

function and produces excellent results with a much lower preheat time. It also reduces overbaking around the edges - a common complaint when cooking in the Templemichael Business Park,

Waveware Limited, Longford, Ireland

Tel: +353 43 45929

Webpage: www.waveware.ie

Pictures courtesy of Bord Bia, BIM and McCann E-mail: info@wayeware.ie Trish Oatmeal



